

ATOMIC SPEEDOMETERS

Presentation made by Dave Lochbaum
Director, Nuclear Safety Project
Union of Concerned Scientists
at the NIRS International Webinar

March 9, 2015



Source: flickr photo by David Lofink

Local, state and federal officials post limits on how fast people can drive their vehicles along roads under normal conditions. The posted speed limits are risk-informed because they vary from road to road depending on risk factors such as congestion and access options. Fifty-five miles per hour is commonly posted on limited access highways.

Vehicles are equipped with speedometers to provide drivers with the ability to determine whether they are complying with the posted speed limits.



Source: flickr photo by _sarchi



Source: flickr photo by James G

Law enforcement officers have radar guns to give them ways to determine whether drivers are complying with the posted speed limits, too.

When the police's radar gun indicates that a vehicle is traveling faster than the posted speed limit, its driver can expect to receive a traffic ticket.



Source: flickr photo by Chris Yarzab


An analogous system is applied to nuclear power plant safety. In the mid 1980s, the NRC adopted a [safety goal](#) for the operation of nuclear power plants: *core damage frequency (CDF) less than $1E^{-04}$ per reactor year*. This goal addressed odds of a reactor core meltdown. The $1E^{-04}$ per reactor year scientific notation nomenclature translates into a likelihood of experiencing a core meltdown no more often than once every 10,000 reactor years.

This safety goal is essentially the nuclear speed limit. Operating a nuclear plant with a core damage frequency greater than $1E^{-4}$ per reactor year does not mean that an accident will happen any more than driving a car faster than the posted speed limit does not mean it will have an accident. But doing so increases the chances of an accident and is therefore unacceptable.

Plant owners developed [probabilistic risk assessments](#) (PRAs), sometimes called probabilistic safety studies (PSAs), that calculate the core damage frequencies for their reactors. These PRAs function like atomic speedometers in providing owners with something to compare against the nuclear speed limit signs. The accident risk must be calculated because it cannot be directly measured like vehicle speeds.

The NRC developed [Standardized Plant Analysis Risk](#) (SPAR) models that calculate the core damage frequencies for reactors. The NRC has expended considerable effort and resources to understand the [difference between PRA and SPAR results](#) for individual reactors and, when appropriate, to narrow those differences. The SPAR models function like radar guns in providing the NRC with something to compare against the nuclear speed limit signs.

I went back and reviewed the risks calculated by plant owners' PRAs and NRC's SPAR models for significant nuclear safety violations identified since the NRC initiated its [Reactor Oversight Process](#) in spring of 2000. The ROP categories safety violations in four colors: green, white, yellow and red in order of increasing risk. Basically, I examined yellow and red findings issued by the NRC since 2000.



The red columns are the NRC’s SPAR results. The blue columns are the owners’ PRA results.

The closest agreement involved the standby shutdown facility violation at Oconee. The NRC’s calculated risk was only twice as high as the plant owner’s calculated risk.

The least agreement involved the flood protection violation at Watts Bar. The NRC’s calculated risk was nearly 800 times higher than the plant owner’s calculated risk.


The atomic speedometers and the nuclear radar guns either are not well calibrated or they are examining entirely different things!

To put this risk ciphering gap into perspective, let's return to the speed limit analogy.

Event	Plant Owner's Atomic Speedometer	NRC's Radar Gun
Oconee standby shutdown facility	55 mph	110 mph
Indian Point 2 steam generator tube leak	55	238
Browns Ferry RHR valve – high	55	240
Palo Verde voided ECCS piping	55	361
Arkansas Nuclear One flooding	55	382
Fort Calhoun trip contactor	55	393
Arkansas Nuclear One stator drop effect on Unit 1	55	688
Arkansas Nuclear One stator drop effect on Unit 2	55	856
Fort Calhoun flooding	55	2,095
Monticello flooding	55	2,220
Browns Ferry RHR valve – low	55	5,500
Watts Bar flooding	55	42,853

When Oconee's atomic speedometer registered 55 miles per hour, the NRC's radar gun clocked the reactor speeding along at 110 miles per hour. And that was the closest match

When Watts Bar's atomic speedometer showed 55 miles per hour, the NRC's radar gun indicated a smokin' fast 42,853 miles per hour!



Source: NRC [Regulatory Guide 1.174](#)

For example, this chart is Figure 4 from the NRC's Regulatory Guide 1.174. The horizontal axis across the bottom represents core damage frequency (CDF) that increases going from left to right. The 10^{-4} value in the center is the NRC's subsidiary safety goal value. CDFs to the left meet the goal; CDFs to the right do not meet it.

The vertical axis along the left represents the delta core damage frequency (Δ CDF). The Δ CDF is the increase in the CDF caused by some actual or postulated condition. For example, the typical nuclear reactor has two emergency diesel generators to power essential equipment when normal power supplies are lost. Only one emergency diesel generator needs to run, the second is installed as a fully redundant backup to increase the chances that one works. The Δ CDF might be for removing one emergency diesel generator from service for maintenance longer than the outage time assumed in calculating the CDF.

Figure 4 governs when activities that increase CDF can be undertaken. When the CDF is low and the Δ CDF is also low, the placement in Region III means the change is acceptable.

But when the Δ CDF is large (i.e., in Region I) or the existing CDF is high (i.e. to the right of Region III), the change is unacceptable.

It makes sense. As the CDF increases, the amount of additional risk (Δ CDF) that can be tolerated decreases. At some point, the CDF becomes too high to allow any additional risk.

Conversely, as the CDF decreases, the amount of additional risk that can be tolerated increases. But the amount of additional risk at some point becomes too high to accept even when the CDF is quite small.

The large differences between the atomic speedometers and the nuclear radar guns render this chart useless.

The PRA and SPAR model results were Δ CDFs. Differing by factors of 2 to 800 mean that plant owners and the NRC literally are not on the same figure when it comes to determining whether Δ CDFs fall in Region III, Region II, or Region I.

The posted speed limit, speedometer, and radar gun trilogy works because speedometers and radar guns yield reasonably comparable values. They would be entirely useless if a speedometer showed 40 miles per hour and a radar gun indicated 80 miles per hour.

It's pointless to post speed limits and then rely on atomic speedometers and nuclear radar guns that disagree by so much.

The PRAs and SPAR models cannot be used for anything other than amusing storytellin' and non-productive time-wastin' until their results have closer agreement. Differing by factors of 2 to 800 about risks doesn't allow risk-informed decision-making. It supports risk-deformed decision-making.